TELL-400

Cod. **T400P45F** (4,5/.177) F
Cod. **T400P55F** (5,5/.22) F

Cod. **T400P45S** (4,5/.177) Strong
Cod. **T400P55S** (5,5/.22) Strong



200202	Front sight	**100442**	Safety	**100433**	Support pin 6x30,2
100296	Front sight screw	**000317**	Piston seal	**100434**	Main spring support screw
200004	Rear sight	**200418**	Piston	**000026**	Toothed washer
100003	Rear sight fixation screw	**300453**	Trigger assembly	**100027**	Lateral screw
100094	Rear sight screw, vertical	**200470**	Trigger group	**100529**	Trigger guard front screw
000005	O ring	**000454**	Pression adjusting spring	**000430**	Trigger guard
000006	Compressor spring	**000457**	Pression adjusting screw	**100431**	Trigger guard rear screw
000007	Compressor ball	**200440**	Main spring support	**B00425**	Butt stock
100008	Lateral washer	**000446**	Hook pin	**000420**	Main Spring
000293	Lever washer	**100447**	Trigger hook	**000420_CN**	Main Spring (Strong)
100410	Lever	**000449**	Trigger hook spring	**000419**	Main spring front guide
100011	Lever pin	**100450**	Sear pin 3x10,3	**T0P40015**	Tube
100012	Cocking cam	**100451**	Sear	**T4P40001_F**	Barrel (4,5) F
100013	Hinge pin screw	**100458**	Hook support	**T5P40001_F**	Barrel (5,5) F
100014	Set screw	**000461**	Hook support hinge pin	**T4P40001_S**	Barrel (4,5) Strong
				T5P40001_S	Barrel (5,5) Strong